

## **Final Report**

# **INVESTIGATIONS INTO MIRROR FABRICATION METROLOGY ANALYSIS**

Contract No. NAS8-38609, D.O. 74  
UAH Account No. 5-33359/60

Submitted to:

NASA/MSFC  
Marshall Space Flight Center, AL 35812

Submitted by:

Center for Applied Optics  
University of Alabama in Huntsville  
Huntsville, AL 35899

August 1994

N95-13841

Unclass

G3/74 0028269

(NASA-CR-196522) INVESTIGATIONS  
INTO MIRROR FABRICATION METROLOGY  
ANALYSIS Final Report No. 4, 1 Jun.  
1993 - 31 Aug. 1994 (Alabama  
Univ.) 71 p

## 1. ABSTRACT

This final report describes the work performed under this delivery order from June 1993 through August 1994. The scope of work included three distinct tasks in support of the AXAF-I program. The objective of the first task was to perform investigations of the grinding and polishing characteristics of the zerodur material by fabricating several samples. The second task was to continue the development of the integrated optical performance modeling software for AXAF-I. The purpose of third and final task was to develop and update the database of AXAF technical documents for an easy and rapid access.

The MSFC Optical and metrology shops were relocated from the B-wing of Building 4487 to Room BC 144 of Building 4466 in the beginning of this contract. This included dismantling, packing and moving the equipment from its old location, and then reassembling it at the new location. A total of 65 zerodur samples, measuring 1" x 2" x 6" were ground and polished to a surface figure of  $\lambda/10$  p-v, and a surface finish of 5Å rms were fabricated for coating tests. A number of special purpose tools and metal mirrors were also fabricated to support various AXAF-I development activities. In the metrology area, the ZYGO Mark IV interferometer was relocated and also upgraded with a faster and more powerful processor. Surface metrology work was also performed on the coating samples and other optics using ZYGO interferometer and WYKO profilometer.

A number of new features have been added to the GRAZTRACE program to enhance its analysis and modeling capabilities. A number of new commands have been added to the command mode GRAZTRACE program to provide a better control to the user on the program execution and data manipulation. Some commands and parameter entries have been reorganized for a uniform format. The command mode version of the convolution program CONVOLVE has been developed. An on-line help system and a user's manual have also been developed for the benefit of the users.

The database of AXAF technical documents continues to progress. The titles, company name, date and location of over 390 documents have been entered in this database. This database provides both a data search and retrieval function, and a data adding function. These functions allow a user to quickly search the data files for documents or add new information. A detailed user's guide has also been prepared. This user guide includes a document classification guide, a list of abbreviations, and a list of acronyms, which have been used in compiling this database of AXAF-I technical documents.

install and certify the upgrade to the ZYGO Mark IV Interferometer system. The system is now a ZYGO Mark IV-xp that has a faster and more powerful processor.

The fabrication of 55 AXAF coating samples was completed. The samples measure 1 x 2 x 6 inches and are made of Zerodur. The 2 x 6 inch optical surface was ground and polished to a surface figure of one-tenth wave P-V (at 632.8 nm.) and a surface finish of better than 5 angstroms (RMS). The other surfaces were buffed to an inspection shine.

Also, for polishing the samples, the old lap was stripped off the 48-inch planetary polisher and the entire machine was cleaned. This was necessary since the machine was contaminated when it was moved from MSFC Building 4487 and set up in the new Building 4466. The repairs were also performed on the continuous polisher to ensure a problem-free operation including the replacement of the drive belt on spider and the replacement/adjustment of the spring on pan sweep.

UAH personnel also performed a controlled grind on the optical surface of an additional 10 bars. These bars will be used as coating witness samples to be tested in a synchrotron chamber by SAO personnel. The final polishing was performed on these bars to obtain a figure of  $0.3 \lambda$  to  $0.5 \lambda$  prior to deblocking the individual bars. After deblocking, the bars were tested individually to ascertain the figure readings. The bars that met  $0.1 \lambda$  requirement were wrapped up and set aside (5 total). The remaining bars are being placed, 2 at a time in a septum, on 48" continuous polisher and polished until the figure requirement is met.

UAH personnel also provided support to AXAF-I program by fabricating various tooling, in the machine shop and in the glass shop. Using the WYKO profilometer, various measurements on several AXAF nickel-plated samples were performed to explore various polishing techniques. This also required fabrication of appropriate tooling.

Ed Horton resigned from UAH near the beginning of this delivery order. However, he was replaced by Greg Martin without any adverse effect on the work to be accomplished.

#### **4. DEVELOPMENT OF PERFORMANCE PREDICTION SOFTWARE (TASK 2)**

The first software task was the development of an image evaluation program to model the detector scan output. The high frequency surface errors had to be taken into account as surface scattering. The geometric ray trace result obtained by GRAZTRACE had also to be convolved with the scattering data in the detector scan model.


The convolution program CONVOLVE is an image analysis software package. With the CONVOLVE and GRAZTRACE programs, the performance of an x-ray system can be predicted through modeling of various detector scans. The program convolves the x-ray source distribution, the GRAZTRACE image data and the mirror surface scattering data. The

- b. File exist check has been added to the program. In the "restore" command, the file check will tell the user to retry if the file does not exist. In the "save" command, the file check will notify the user to either overwrite or retry if the file already exists.
- c. EDI command common area error has been fixed.
- d. ZLI command has been added to set the "zlim" parameter.
- e. Help file access from any directory has been provided by defining the full path.
- f. Parameter entry order in multi-field commands has been reorganized to have a uniform format.
- g. Inquiry command has been enhanced to allow the users to check all multi-dimensional data at any level.
- h. Sequential file execution mode has been implemented to allow the command mode GRAZTRACE to perform macro and batch running.
- i. Temporary file for the built-in editor now has a random file name to prevent the error caused by multiple execution of the program in the same directory.
- j. SES and OUT commands have been added to save the executed commands and output text to files. ECH command has also been added to echo the command input.
- k. Recover feature has been added to allow the user to recover the whole session after an abnormal termination of the program.
- l. Source codes and help file have been put into SCCS (source code control system) to monitor the changes, and to protect them from accidental deletion. Now several people can work on the code development without interfering with each other.

A general purpose translation program has been completed to convert the output data files of finite element analysis programs such as NASTRAN and COSMOS/M to GRAZTRACE deformation file ( dfm file). This translation program can accept data in the form of standard output files or list files, and provides the flexibility of using randomly spaced grid points for FEA. Also, there is no restriction on the number and order of node points. When the translation program is executed, the user can interactively perform coordinate transformation, origin shift and scaling and axial length changes. This translation program was tested and evaluated for predicting the effects of structural distortions for the Solar X-ray Imager (SXI) electroformed mirror

A similar scheme will be used for developing a translation program to convert the surface metrology data to a format compatible for GRAZTRACE input. A meeting was held at MSFC to discuss the interface of metrology data with the GRAZTRACE program. MSFC

## SOFTWARE FOR AXAF-I PERFORMANCE ANALYSIS



origin and content. Documents having the same classification code are further ordered by date.

In addition to the classification guide, there are two other appendices. Appendix B contains a list of 234 abbreviations related to the AXAF project. Appendix C contains a list of 383 acronyms, also associated with the AXAF project.

### **Data Files**

Initially it was thought that some automated method could be developed, using the powerful UNIX operating system utilities for (text) pattern searching and processing, to standardize the existing data files. However, the non-uniformity of the data files coupled with the fact that the actual documents themselves were in disarray soon made it clear that the best approach to establishing the database and organizing the documents would be to start from ground zero.

Once the work of creating a standard format for the new data files and writing the database program was done, work on establishing the data files commenced. The work on the data files began by pulling all of the documents from a particular company out of its filing cabinet. The documents were then sorted and entered into the database. Then, each document was placed in its own manila folder with a new detailed label and re-filed. Once all of the documents from one company were completed, the process was repeated for the documents from another.

### **Present State of the Database**

Work on entering the documents into the database has slowed, in part, because the UAH person is also working on another contract with Dr. Amzajerjian and Mr. Gary Spiers.

As of the date of this report, documents from five of the nine active AXAF files have been entered into the database and organized: TRW, Inc., Science Instruments, OCLI, Eastman Kodak Co., and SAO.

Currently, the documents from Schott Glaswerke are being entered into the database. The four remaining files whose documents have yet to be entered and subsequently re-filed are HDOS, Project (MSFC), TMA (Technology Mirror Assembly, an AXAF predecessor), and AXAF S (spectroscopic). There are, as of yet, no documents associated with an eleventh and inactive file which is for Ball Aerospace, Inc.

# **APPENDIX 1**

## **CONVOLVE User Manual**

### **Command Mode X-ray Image Analysis Program**

## Section 1. INTRODUCTION

Command Mode CONVOLVE allows the users to interactively use the convolution program in image analysis through various detector scans modelling. The command structure and format are the same as those in command mode GRAZTRACE. Commands cover input selections, control commands, and scans modeling.

### 1.1 Command summary

More than 30 commands have been furnished in the command interpreter.

#### *Input selections:*

IMF define image ray data file name

EEF define scattering distribution file name

CNV convolve imaging and scattering data

#### *Control commands:*

EXI exit the program

CAN cancel all the options

SYS operating system shell

#### *Image analysis:*

SCA scan area

GRD grid scan

WIN write intensity file

BLB block bounded energy distribution



## Section 2. SAMPLE SESSION

This section contains a detailed and realistic "sample session" in CONVOLVE command mode. This sample session will give user a quick start to become familiar with CONVOLVE program.

The program can be invoked by typing CONV. The command mode prompt CONVOL> will show up. Key in any command interactively, followed by a carriage return <Enter>. To quit the program, use the Exit command. The program will prompt the user to confirm exiting the program.

```
zeus{chen}49>conv
```

```
*****  
*                                     *  
*          IMAGE ANALYSIS          *  
*                                     *  
*****
```

```
CONVOL>IMF sxi3.gtray ! select input image file  
Read in scattering file  
sxi3.gtray
```

```
1 ray intercept file: sxi3.gtray
```

```
rays      20000  
energies  4  
net z shift  0.0000000000000000E+00  
input focal length  0.6573753635237400E+03  
comments 20
```

```
energy values:
```

```
1      -0.1000000000000000E+01
```

```
2      0.2770000000000000E+00
```

weight total 0.1687263016540063E+03  
weight average 0.8436315082700317E-02  
weight rms 0.1529528425530240E-03  
wmin= 0.8164165942176118E-02, wmax= 0.8693121510592393E-02  
CONVOL>EEF sxi.mod.eeout ! select input scattering file  
Read in scattering file  
sxi.mod.eeout

ascii encircled energy file: sxi.mod.eeout

ee values 380  
assumed focal length 0.6573753635237400E+03  
energy 0.2770000000000000E+00  
comments 5

sxi similar to sxt case 3

core reduced to 2.06 arc seconds rms diameter

(design spreading of on-axis image removed)

psd down to 0.05 cyc/mm

d.e.zissa, october 1, 1992

integrated probablilty values		759	
	per centage= 0.04,	displacement (arc sec)=	-239.1730
no. 1,	per centage= 1.00,	displacement (arc sec)=	-11.3440
no. 2,	per centage= 2.00,	displacement (arc sec)=	-8.3162
no. 3,	per centage= 3.00,	displacement (arc sec)=	-6.9237
no. 4,	per centage= 4.00,	displacement (arc sec)=	-6.0493
no. 5,	per centage= 5.00,	displacement (arc sec)=	-5.4212
no. 6,	per centage= 6.00,	displacement (arc sec)=	-4.9344
no. 7,	per centage= 7.00,	displacement (arc sec)=	-4.5383
no. 8,	per centage= 8.00,	displacement (arc sec)=	-4.2052
no. 9,	per centage= 9.00,	displacement (arc sec)=	-3.9186
no. 10,	per centage= 10.00,	displacement (arc sec)=	-3.6674
no. 11,	per centage= 11.00,	displacement (arc sec)=	-3.4440
no. 12,	per centage= 12.00,	displacement (arc sec)=	-3.2426
no. 13,	per centage= 13.00,	displacement (arc sec)=	-3.0590
no. 14,	per centage= 14.00,	displacement (arc sec)=	-2.8901
no. 15,	per centage= 15.00,	displacement (arc sec)=	-2.7333
no. 16,	per centage= 16.00,	displacement (arc sec)=	-2.5869
no. 17,	per centage= 17.00,	displacement (arc sec)=	-2.4494
no. 18,	per centage= 18.00,	displacement (arc sec)=	-2.3198
no. 19,	per centage= 19.00,	displacement (arc sec)=	-2.1972
no. 20,	per centage= 20.00,	displacement (arc sec)=	-2.0809
no. 21,	per centage= 21.00,	displacement (arc sec)=	-1.9705
no. 22,	per centage= 22.00,	displacement (arc sec)=	-1.8653
no. 23,	per centage= 23.00,	displacement (arc sec)=	-1.7651
no. 24,	per centage= 24.00,	displacement (arc sec)=	-1.6695
no. 25,	per centage= 25.00,	displacement (arc sec)=	-1.5782

no. 80,	per centage=	80.00,	displacement (arc sec)=	2.0809
no. 81,	per centage=	81.00,	displacement (arc sec)=	2.1972
no. 82,	per centage=	82.00,	displacement (arc sec)=	2.3198
no. 83,	per centage=	83.00,	displacement (arc sec)=	2.4494
no. 84,	per centage=	84.00,	displacement (arc sec)=	2.5869
no. 85,	per centage=	85.00,	displacement (arc sec)=	2.7333
no. 86,	per centage=	86.00,	displacement (arc sec)=	2.8901
no. 87,	per centage=	87.00,	displacement (arc sec)=	3.0590
no. 88,	per centage=	88.00,	displacement (arc sec)=	3.2426
no. 89,	per centage=	89.00,	displacement (arc sec)=	3.4440
no. 90,	per centage=	90.00,	displacement (arc sec)=	3.6674
no. 91,	per centage=	91.00,	displacement (arc sec)=	3.9186
no. 92,	per centage=	92.00,	displacement (arc sec)=	4.2052
no. 93,	per centage=	93.00,	displacement (arc sec)=	4.5383
no. 94,	per centage=	94.00,	displacement (arc sec)=	4.9344
no. 95,	per centage=	95.00,	displacement (arc sec)=	5.4212
no. 96,	per centage=	96.00,	displacement (arc sec)=	6.0493
no. 97,	per centage=	97.00,	displacement (arc sec)=	6.9237
no. 98,	per centage=	98.00,	displacement (arc sec)=	8.3162
no. 99,	per centage=	99.00,	displacement (arc sec)=	11.3440
	per centage=	99.96,	displacement (arc sec)=	239.1730

CONVOL>ENE ? ! check energy pointer

iener = 2

CONVOL>IMA ? ! check image pointer

ima = 1

CONVOL>CNV ! perform convolution

CNV>GO ! execute the option

iener= 2

nmult= 5

asig2= 0.0000000000000000E+00, csig2= 0.0000000000000000E+00

xsig2= 0.0000000000000000E+00, ysig2= 0.0000000000000000E+00

ugauss= ( 0.1000000000000000E+01, 0.0000000000000000E+00)

xlen2= 0.0000000000000000E+00, ylen2= 0.0000000000000000E+00

urect= ( 0.1000000000000000E+01, 0.0000000000000000E+00)

diam2= 0.0000000000000000E+00

CONVOL>SCA ! scan area

SCA>GO

scanarea output

scan direction ( 0.1000000000000000E+01, 0.0000000000000000E+00)

scan length for centroid calculation 0.3187045698606638E+00

scan width 0.3187045698606638E-01

energy flag 2

centroid ( -0.1594535593398104E-05, 0.8707513390032706E-14)

total weight in full scan 0.5015319716534087E+03

unweighted points in full scan 94366

fraction of weight for centroid calculation 0.9999681625259412E+00

CONVOL>GRD ! grid scan

GRD>GO

lgrdscn rectangular detector scan

19 x points and 19 y points

x full width of scan points 0.1800000000000000E+00

```

0.046 0.008 0.002 0.001 0.000 0.000 0.000 0.000 0.000
y= -0.020| 0.000 0.000 0.000 0.000 0.000 0.000 0.001 0.003
0.009 0.013
0.009 0.003 0.001 0.000 0.000 0.000 0.000 0.000 0.000
y= -0.030| 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.001
0.002 0.002
0.002 0.001 0.000 0.000 0.000 0.000 0.000 0.000 0.000
y= -0.040| 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000
0.001 0.001
0.001 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000
y= -0.050| 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000
0.000 0.000
0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000
y= -0.060| 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000
0.000 0.000
0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000
y= -0.070| 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000
0.000 0.000
0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000
y= -0.080| 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000
0.000 0.000
0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000
y= -0.090| 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000
0.000 0.000
0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000
CONVOL>BLB ! blocked bounded energy distribution
BLB>GO

```

```

lblockbed bounded energy distribution
scan width 0.5000000000000000E-02
center ( -0.1594535593398104E-05, 0.8707513390032706E-14)
scan direction ( 0.1000000000000000E+01, 0.0000000000000000E+00)
normalization 0.5015319716534087E+03
energy flag 2

```

bed values:

no.	full width(sec)	fraction	full width
1	0.0500	0.0316	0.00016
2	0.1000	0.0560	0.00032
3	0.1500	0.0770	0.00048
4	0.2000	0.0955	0.00064
5	0.2500	0.1116	0.00080
6	0.3000	0.1267	0.00096
7	0.3500	0.1406	0.00112
8	0.4000	0.1537	0.00127
9	0.4500	0.1661	0.00143
10	0.5000	0.1783	0.00159
11	0.5500	0.1892	0.00175
12	0.6000	0.1996	0.00191
13	0.6500	0.2091	0.00207
14	0.7000	0.2187	0.00223
15	0.7500	0.2273	0.00239

no.	position (arc sec)	fraction	position
1	-0.1250	0.95939	-0.00040
2	15.5635	0.00188	0.04960
3	31.2520	0.00016	0.09960
4	46.9405	0.00004	0.14960
5	62.6290	0.00000	0.19960
6	78.3176	0.00000	0.24960
7	94.0061	0.00000	0.29960
8	109.6946	0.00001	0.34960
9	125.3831	0.00000	0.39960
10	141.0716	0.00000	0.44960
11	156.7601	0.00000	0.49960
12	172.4486	0.00000	0.54960
13	188.1371	0.00000	0.59960
14	203.8256	0.00000	0.64960
15	219.5141	0.00000	0.69960
16	235.2027	0.00000	0.74960
17	250.8912	0.00000	0.79960
18	266.5797	0.00000	0.84960
19	282.2682	0.00000	0.89960
20	297.9567	0.00000	0.94960

CONVOL>PNS ! pinhole detector scan

PNS>GO

lpinscan circular pinhole detector scan

diameter of scan 0.5000000000000000E-02

scan direction ( 0.1000000000000000E+01,

scan center ( -0.1594535593398104E-05,

energy flag 0

normalization 0.5015319716534087E+03

0.0000000000000000E+00)  
0.8707513390032706E-14)

profile values:

no.	position (arc sec)	fraction	position
1	-23.5328	0.00000	-0.07500
2	-21.0556	0.00000	-0.06711
3	-18.5785	0.00000	-0.05921
4	-16.1014	0.00000	-0.05132
5	-13.6242	0.00000	-0.04342
6	-11.1471	0.00000	-0.03553
7	-8.6700	0.00000	-0.02763
8	-6.1928	0.00000	-0.01974
9	-3.7157	0.00000	-0.01184
10	-1.2386	0.00000	-0.00395
11	1.2386	0.00000	0.00395
12	3.7157	0.00000	0.01184
13	6.1928	0.00000	0.01974
14	8.6700	0.00000	0.02763
15	11.1471	0.00000	0.03553
16	13.6242	0.00000	0.04342
17	16.1014	0.00000	0.05132
18	18.5785	0.00000	0.05921
19	21.0556	0.00000	0.06711

11	22.0000	0.9798	0.07012
12	24.0000	0.9835	0.07649
13	26.0000	0.9862	0.08286
14	28.0000	0.9883	0.08924
15	30.0000	0.9899	0.09561
16	32.0000	0.9911	0.10199
17	34.0000	0.9923	0.10836
18	36.0000	0.9932	0.11473
19	38.0000	0.9940	0.12111
20	40.0000	0.9946	0.12748

CONVOL>**EXI** ! exiting the program  
EXITING THE PROGRAM ? (Y/N)**Y**  
zeus{chen}49>

# INPUT SELECTIONS

Select input data.

## COMMAND MNEMONICS

IMF    EEF    CNV

### THE TASK — Define image ray data file name

Command Syntax	
Screen Prompt	Explanation
<b>IMF [filspec]</b>	
	Define image ray data file name to be used in convolution image analysis.
<b>EEF [filspec]</b>	
	Define scattering distribution data file name to be used in convolution image analysis.

# CONTROL COMMANDS

## COMMAND MNEMONICS

?    GO    CAN    SYS    EXI

## DATA INPUT DESCRIPTION

Command Syntax	
Screen Prompt	Explanation
<b>?</b>	
	? in data field entry will allow to check current value
<b>GO</b>	
	Execute the option using all previously entered option inputs and then return control to the command level
<b>CAN</b>	
	Cancel all inputs to this option and return control to the command level
<b>SYS</b> ['OP SYS COMMAND']	
	Execute operating system commands
<b>EXI</b>	
	Exit from CONVOL to the operating system. When EXI is typed in, a query is issued requiring a Yes or No answer (Y or N); a Y will cancel any option you are in and complete the exit. (Default is N.)



## CONVOLUTION (CNV)

**CNV** convolves scattering distribution with ray distribution.

### COMMAND MNEMONICS

**MUL AGA CGA SSI UGA REC URE DIA ENE DBG**

### DATA INPUT DESCRIPTION

Command Syntax		
Screen Prompt	Explanation	Default
<b>MUL</b> multiplicity		
Multiplicity	Cancel the default set and set desired random multiplicity	5
<b>AGA</b> asig		
axial sigma	Set axial gaussian sigma in arc sec	0
<b>CGA</b> csig		
circumferential sigma	Set circumferential gaussian sigma in arc sec	0
<b>SSI</b> xsig ysig		
x sigma, y sigma	Set x and y sigma of fixed gaussian distribution in arc sec	0, 0
<b>UGA</b> ugauss(1) ugauss(2)		
direction	Set direction of x axis of gaussian distribution	1, 0
<b>REC</b> xlen ylen		
widths	Set rectangular distribution width in arc sec	0, 0

# SCA

## SCAN AREA (SCA)

SCA find centroid and normalization of scan

### COMMAND MNEMONICS

USC SLE DSI ENE

### DATA INPUT DESCRIPTION

Command Syntax		
Screen Prompt	Explanation	Default
<b>USC</b> uscan(1), uscan(2)		
Scan direction	Set scan direction vector	1, 0
<b>SLE</b> flen		
Scan length	Define range of scan in mm	100*fac
<b>DSI</b> width height		
Detector size	Define detector size in mm	10*fac, 10*fac
<b>ENE</b> iener		
Energy pointer	Set energy pointer	2

# WIN

## PRINT INTENSITY (WIN)

**WIN** prints out grid of intensity values.

### COMMAND MNEMONICS

**NGR WGR**

### DATA INPUT DESCRIPTION

Command Syntax		
Screen Prompt	Explanation	Default
<b>WGR</b> xwidth ywidth		
Grid widths	Set grid size in mm	0.1, 0.1

# BLS

## BLOCK SCAN (BLS)

BLS block scan

### COMMAND MNEMONICS

NPTS DSI SLE CEN USC NOR ENE

### DATA INPUT DESCRIPTION

Command Syntax		
Screen Prompt	Explanation	Default
<b>NPTS</b>		
Number of points	Set sample number	20
<b>DSI</b> width height		
Detector size	Set detector size	10*fac, 10#fac
<b>SLE</b> flen		
Scan length	Set scan length	100*fac
<b>CEN</b> xcem ucem		
Center of scan	Set center of scan	0, 0
<b>USC</b> uscan(1) uscan(2)		
Direction vector	Set scan direction vector	1,0
<b>NOR</b> fnorm		
Normalization	Set normalization factor	
<b>ENE</b> iener		
Energy pointer	Set energy pointer	2

CONVOL

# PNS

## PINHOLE SCAN (PNS)

PNS scans pinhole detector

### COMMAND MNEMONICS

NPT DIA CEN USC NOR ENE

### DATA INPUT DESCRIPTION

Command Syntax		
Screen Prompt	Explanation	Default
<b>NPT</b> npts		
Number of points	Set sample number	20
<b>DIA</b> diam		
Detector diameter	Set detector diameter	0
<b>CEN</b> xcen ycen		
Center of grid	Set center of grid	0, 0
<b>USC</b> uscan(1), uscan(2)		
Scan direction	Set scan direction vector	1, 0
<b>NOR</b> fnorm		
Normalization	Override normalization factor	
<b>ENE</b> iener		
Energy pointer	Set energy pointer	2

CONVOL

**INTERCEPT SHIFT (SHI)**

**SHI** shifts ray intercepts in axial (z) direction and updates net shift value

**THE TASK — Intercept shift**

Command Syntax		
Screen Prompt	Explanation	Default
<b>SHI shift</b>		
	Shift the ray intercept plane along axial direction by (shift) and update net shift value (zshift)	

## **APPENDIX 2**

### **AXAF DATABASE USER'S GUIDE**

## **OVERVIEW**

The AXAF database program allows you to both search the AXAF data files for information related to a specific key word or time (period), and to add new entries to the AXAF data files. In order to use the database, you must first change to the directory named AXAFDB. Then type "axafdb<RETURN>." The database program will guide you from there.

## **GENERAL**

The data files do not contain the actual documents. Rather, "header information" (the date, the title, the location, and the filing order of the document) is stored in the data files in one line records. Utilizing this header information allows for quick, automated searches through large numbers of documents. Many abbreviations and acronyms are used in order to fit as much of the title information as possible into each data record. A list of abbreviations may be found in Appendix B and a list of acronyms may be found in Appendix C.

## **LIMITATIONS OF THE DATA SEARCH & RETRIEVAL FUNCTION**

The data search and retrieval function takes the key word that you enter, which is simply a character string representing a word, word fragment, acronym, abbreviation, date, or etc., and searches the data file you specify for an occurrence of that string, either alone or within a larger string.

However, the search and retrieval function cannot perform multi-level searches. For example: Say you want to find all the documents in the Smithsonian Astrophysical Observatory (SAO) files on the X-ray Detection System. Entering "XDS<SPACE> SAO<RETURN>" when the search and retrieve function prompts you for a key word will return an error.

See SUGGESTIONS ON SEARCHING for a complete discussion of search methods.

## **MAIN DATABASE MENU**

When the AXAF database program is run, the main menu will appear which looks like the following:

\*\*\* AXAF database \*\*\*

Do you want to:

1. Search the database
2. Update the database
3. Quit the database

Enter the number of your selection...

At the prompt, enter the number corresponding to the function you wish to perform.



## **SORT THE FINDINGS ALPHABETICALLY OR CHRONOLOGICALLY**

Next, you will be asked if you want the findings of the search sorted chronologically, with the most recent date last, or alphabetically. If you want the findings sorted chronologically, enter "C." To have the findings sorted alphabetically, enter "A."

## **DISPLAY THE FINDINGS**

The program will search the specified data file for the character string you entered. Then it will sort its findings in the format you indicated and display them. The findings will be displayed one screen at a time. To get the next screen of the findings to display, press the SPACE bar once. To see just the next line of the findings, press the RETURN key once. If you wish to stop displaying the findings in mid stream, press the "Q" key.

## **PRINT THE FINDINGS**

When all of the findings for a particular key word have been displayed or when you abort the display process by pressing the "Q" key, you will be asked if you want a hard copy of the findings. If so, enter "Y" and the findings will be printed on pvenus. If you elect not to have the findings printed out, enter "N."

## **SEARCH AGAIN**

Next, you will be asked if you want to search on another key word. If not, enter "N." If so, enter "Y" and you will also be asked if you want to search the same data file. If you want to search the same data file, enter "Y." If not, enter "N" and you will be shown the data file menu again and asked to select a new file to search. Finally, you will be asked to enter the key word for the new search and the process will start over.

## **SUGGESTIONS ON SEARCHING**

There are a number of ways which you can search the database for information. You can search by document date, classification code, title, or location. You may also search for a word, word fragment, abbreviation, or acronym occurring in the information for which you are looking.

## **SEARCHING BY DATE**

Each document in the database has a date. The dates are of the format yearmonthday (i.e. for a document whose date is June 14, 1994, the date in the database for that document would be 19940614 where 1994 is the year, 06 is the month, and 14 is the day). If you know any part of the date of the document or documents you want to find, then, when you are prompted to enter the key word, enter a year (e.g. 1993), or a month (e.g. 199312 for December 1993), or a day (e.g. 19931229 for December 29, 1993), and the database will return information on all the documents which fall into that particular time frame.

If you know a key word, such as "MIRROR," that is in the title of the document or documents you are searching for, typing "MIR<RETURN>" when you are prompted to enter the key word for the search will direct the database to display information on all the documents whose title contains the string "MIR."

### DATA UPDATING FUNCTION

The database data updating function allows you to catalog information about old or new AXAF documents into the database. You will be prompted to enter four (4) items of information about the document you are cataloging: the FILENAME, the DATE, the CLASSIFICATION CODE, and the TITLE.

After entering the items, you will be shown the new entry and asked to confirm whether or not it is correct.

Finally, you will be asked if you want to add another entry to the current data file or to another data file. If you want to add another entry to the current data file, you will be returned to the place where you are prompted for the date of the document and the process will continue from there. If you want to add entries to a different data file, you will be returned to the file menu where you can select a different file to update and the whole process will repeat from there.

The most important thing to remember when adding new entries is to insure that they are entered accurately. You will have two opportunities to review the items of each entry. The first time will be just after you enter a particular item of information. The second time will be just before the new entry is added to the database, where you will see the complete entry as it will appear in the data files.

### FILE NAME

The data updating function first displays a menu of the individual data files, most all of which are directly associated with a company working on the AXAF project. There are at present eleven (11) individual data files. The menu looks like this:

#### SELECT A FILE TO UPDATE

1. AXAF BALL
2. AXAF HDOS
3. AXAF KODAK
4. AXAF OCLI
5. AXAF PROJ
6. AXAF S
7. AXAF SAO
8. AXAF SCHOTT
9. AXAF SI
10. AXAF TMA
11. AXAF TRW

Enter the number of your selection...

## TITLE

In this section you are prompted for the title of the document. The title will be, at most, forty (40) printing characters. (Printing characters are alphanumerics, underscores, hyphens, and etc.) The letters used must be all capital. You should use the abbreviations and acronyms listed in Appendices B and C in order to fit as much of the title as possible into the entry. Once the title is entered, the program will echo it to you for confirmation. If it is correct, respond by entering "Y." If the title is incorrect, enter "N" and you will be asked to enter the title again. If an error occurs, simply heed the error message and re-enter the title accordingly. Use the scale on the line just above the prompt to gauge how many characters you have typed.

It is important that the words which are completely spelled out are spelled correctly. Otherwise, when using a particular word for a search, you will not be able to find information on a document which contains that word misspelled.

## VERIFYING & ADDING

Now, the complete new entry is presented to you just as it will appear in the data file. This is the last chance to abort adding the entry to the data file. You will be asked to confirm that the entry is correct and that you desire to add it to the data file you specified. If you want to add the entry, enter "Y." If you decide not to add the new entry, enter "N."

## MORE DATA

Next, you will be asked if you want to add another entry to the data file you are currently updating. If so, enter "Y" and the program returns to the DATE section and begins asking you for information about the new entry. If you are done adding information to the current data file, enter "N" and you will be asked if data is to be added to another file. If you want to add data to another file, enter "Y" and the program returns to the FILE NAME section and asks you to select another file to update. If not, enter "N" and the program returns to the Main Menu.

## MISCELLANEOUS

This section contains information on various topics not directly related to the operation of the database.

## REMOVING UNWANTED ENTRIES FROM THE DATA FILES

At this time, there is no provision for deleting unwanted entries from the database. The only way to do this is to textedit the individual data file, remove the unwanted entry by "cutting" out that specific line, and then saving the data file. You must also do the same to the master data file.

Since the operating system keeps backup copies of files (denoted by an "%" symbol at the end of the file name), it would be prudent to remove the backup file from the disk once you are through deleting entries. Otherwise, you will be using almost twice the necessary disk space for that particular file.

PRELIMINARY DESIGN AUDIT (PDA)  
VETA-II (V2)  
MIRROR BLANKS (MBL)

OPTICAL COATING LABORATORY, INC. (OC)  
COATING PROGRAM (CP)  
CLEANING (CLNG)  
COATING (CTG)

AXAF PROJECT (AP)

AXAF SPECTROSCOPIC (AS)

SMITHSONIAN ASTROPHYSICAL OBSERVATORY (SA)  
FINAL REPORT (FR)  
GENERAL (GEN)  
FEA (FEA)  
FLAT STUDY (FS)  
FLEXURE MOUNT (FLEX)  
LAMAR (LAMAR)  
OSAC (OSAC)  
THERMAL PRECOLLIMATOR VIGNETTING STUDY (TPVS)  
HRMA (HRMA)  
VETA-I (V1)  
ALIGNMENT (ALGNMNT)  
BLUEPRINT (BLPRNT)  
EXTRA LESSONS (EL)  
FULL WIDTH HALF MAXIMUM (FWHM)  
X-RAY DETECTION SYSTEM (XDS)  
LEON VAN SPEYBROECK (LVS)  
MIRRORS (MIR)  
COATING & REFLECTIVITY (CTG)  
CONTAMINATION (CONTAM)  
FABRICATION (FAB)  
METROLOGY (MET)  
SPECIFICATION (SPEC)  
MIRROR BLANK (MBL)  
MONTHLY REPORTS (MR)  
QUARTERLY REVIEWS (QR)  
SCIENCE INSTRUMENTS (SI)  
TRIP REPORTS (INCLUDING SCHEDULE REVWS & MTGS) (TR)  
HUGHES DANBURY OPTICAL SYSTEMS/PERKIN-ELMER (HDOS)

STRUCTURE & MECHANICAL SUBSYSTEM (SM)  
THERMAL CONTROL SUBSYSTEM (TC)  
ELECTRICAL & POWER SUBSYSTEM (EP)  
COMMUNICATION & COMMAND & DATA MANAGEMENT SUBSYSTEM (CC)  
POINTING CONTROL & ASPECT DETERMINATION SUBSYSTEM (PA)  
FLIGHT SOFTWARE (FS)  
SCIENCE INSTRUMENTS (SI)  
FOCAL PLANE SCIENCE INSTRUMENTS (FPSI)  
HIGH RESOLUTION CAMERA & LOW ENERGY TRANSMISSION GRATING  
OBJECTIVE TRANSMISSION GRATING (OTG)

COMPAR - COMPARISON  
COMPUT - COMPUTATION  
CONCENT - CONCENTRATION  
CONFIG - CONFIGURATION  
CONST - CONSTANT  
CONT - CONTINUE / CONTINUATION  
CONTAM - CONTAMINATION  
CONTING - CONTINGENCY  
CRCTNG - CORRECTING  
CRIT - CRITERIA  
CRITCL - CRITICAL  
CTG - COATING  
CVR - COVER  
CVRG - COVERAGE  
CYL - CYLINDER  
D  
DAT - DATA  
DB - DECIBEL (db)  
DC - DIRECT CURRENT (dc)  
DECONV - DECONVOLUTION  
DECR - DECREASE  
DEF - DEFINITION  
DEMO - DEMONSTRATION  
DESGN - DESIGN  
DET - DETECTOR  
DEV - DEVELOPMENT / DEVICE  
DIA - DIAMETER  
DIAG - DIAGONAL / DIAGRAM  
DICT - DICTIONARY  
DIFCLT - DIFFICULT  
DIST - DISTANCE  
DISTR - DISTORTION  
DISTR - DISTRIBUTION  
DLVRY - DELIVERY  
DOC - DOCUMENT / DOCUMENTATION  
DRWNG - DRAWING  
E  
EFFCTV - EFFECTIVE  
ELEM - ELEMENT  
ENHANC - ENHANCEMENT  
ENV - ENVIRONMENT  
EQUIP - EQUIPMENT  
ESTIM - ESTIMATE  
EV - ELECTRON VOLT (eV)  
EVAL - EVALUATE, EVALUATION  
EXEC - EXECUTIVE

MAT - MATERIAL  
MBL - MIRROR BLANK  
MEAS - MEASUREMENT  
MECHAN - MECHANISM  
MGMT - MANAGEMENT  
MIR - MIRROR  
MIRCLS - MIRROR CELLS  
MM - MILLIMETER (mm)  
MODIF - MODIFICATION  
MTG - MEETING  
N  
NI - NICKEL (Ni)  
NMI - NAUTICAL MILE (nmi)  
O  
OB - OBSERVATORY / OBSERVATION  
OBSTR - OBSTRUCTION  
OPER - OPERATING / OPERATION  
OVRVW - OVERVIEW  
P  
PARAM - PARAMETERS  
P-E - PERKIN-ELMER  
PERF - PERFORMANCE  
PKG - PACKAGE  
PLSHNG - POLISHING  
PRECIS - PRECISION  
PRED - PREDICTIONS  
PRELIM - PRELIMINARY  
PREP - PREPARE  
PRES - PRESENTATION  
PROC - PROCUREMENT  
PROCED - PROCEDURE  
PROG - PROGRAM  
PROP - PROPERTY / PROPOSAL  
PSI - POUNDS PER SQUARE INCH (psi)  
PT - PLATINUM (Pt)  
PUB - PUBLICATION  
Q  
QLTY - QUALITY  
R  
RECOM - RECOMMEND / RECOMMENDATION  
RED - REDUCTION  
REDESGN - REDESIGN  
REF - REFERENCE  
REL - RELATED  
REPL - REPLICATION  
REQ - REQUIREMENTS

VERIF - VERIFICATION

VIBR - VIBRATION

VOL - VOLUME

W

WRKNG - WORKING

X

XLATION - TRANSLATION

XMITTAL - TRANSMITTAL

XPORT - TRANSPORT

Y

Z

ZEROD - ZERODUR



BER - BIT ERROR RATE  
BMLY - BARE MIRROR LIFT YOKE  
BND - BEAM NORMALIZATION DETECTOR  
BOD - BRIGHT OBJECT DETECTOR  
BSSD - BALL SPACE SYSTEMS DIVISION

C

CA - CLEAR APERTURE  
CAAS - CELL ASSEMBLY ALIGNMENT SYSTEM  
CALDS - COMPUTER AIDED LAP DESIGN SOFTWARE CSCI (AXAF POD) (IBM BASED)  
CAP - CENTER APERTURE PLATE  
CAPA - CENTER APERTURE PLATE ASSEMBLY  
CATS - COUNTER APERTURE TRANSLATION SYSTEM  
CBA - CENTER BAFFLE ASSEMBLY  
CCD - CHARGE COUPLED DEVICE  
C&CDM - COMMAND AND COMMUNICATION AND DATA MANAGEMENT SUB-SYSTEM  
CD - CENTROID DETECTOR  
CDA - CRITICAL DESIGN AUDIT  
CDM - COMMAND AND DATA MANAGEMENT  
CDR - CRITICAL DESIGN REVIEW  
CEI - CONTRACT END ITEM  
CFE - CONTRACTOR / CUSTOMER FURNISHED EQUIPMENT  
CIDS - CIRCULARITY AND INSIDE DIAMETER GAUGE  
CIDSS - CIRCULARITY AND INNER DIAMETER STATION CSCI (PC BASED)  
CIL - CRITICAL ITEMS LIST  
CM - CONTAMINATION MONITOR  
CMP - CONTAMINATION MONITORING PLAN  
CPSS - COATING PROCESS SELECTION STUDY  
CPU - CENTRAL PROCESSING UNIT  
CR - CLEAN ROOM  
CRU - CONTINGENCY REPLACEABLE UNIT  
CS - CALIBRATION SPECTROMETER  
CSC - COMPUTER SOFTWARE COMPONENT  
CSCI - COMPUTER SOFTWARE CONFIGURATION ITEM  
CTD - CHARGE TRANSFER DEVICE  
CTE - COEFFICIENT OF THERMAL EXPANSION  
CWS - CONTAMINATION WITNESS SAMPLES

D

DATAFILT - DATA FILTERING ANALYSIS CSC (VAX BASED)  
DB - DATA BASE SOFTWARE CSC (VAX BASED)  
DDA - DOOR DRIVE ASSEMBLY  
DDT&E - DESIGN, DEVELOPMENT, TEST, & EVALUATION  
DOD - DEPARTMENT OF DEFENSE  
DOF - DEGREE OF FREEDOM  
DR - DATA REQUIREMENTS

GSF - GLASS SUPPORT FIXTURE  
GSFC - GODDARD SPACE FLIGHT CENTER  
GT - GLASS THICKNESS  
GT - GUIDE TUBE  
GVS - GUIDE TUBE VACUUM SUBSYSTEM  
GVW - GATE VALVE WINDOW  
GWA - GROUND WIRE ATTACHMENT  
H  
H - HYPERBOLOID  
HATS - HRMA ALIGNMENT TEST SYSTEM  
HCE - HRMA CONTROL ELECTRONICS  
HDOS - HUGHES DANBURY OPTICAL SYSTEMS  
HEAO - HIGH ENERGY ASTRONOMICAL OBSERVATORY  
HETA - HRMA ENGINEERING TEST ARTICLE  
HETG - HIGH ENERGY TRANSMISSION GRATING  
HGA - HIGH GAIN ANTENNA  
HIRA - HARDWARE INSERTION AND RETRACTION ASSEMBLY  
HMA - HRMA MODULE ASSEMBLY  
HMSS - HRMA MODULE SUPPORT STRUCTURE  
HOSC - HUNTSVILLE OPERATIONS SUPPORT CENTER  
HPA - HRMA POSITIONING CONTROL  
HRC - HIGH RESOLUTION CAMERA  
HRI - HIGH / HRMA RESOLUTION IMAGER  
HRMA - HIGH RESOLUTION MIRROR ALIGNMENT/ASSEMBLY  
HST - HUBBLE SPACE TELESCOPE  
HVAC - HEATING, VENTILATION, AIR CONDITIONING  
HW - HARDWARE

I

IAS - IMAGE ACQUISITION SYSTEMS  
IC - INSTRUMENT CHAMBER  
I&C - INSTRUMENTATION AND COMMUNICATION  
ICD - INTERFACE CONTROL DRAWING / DOCUMENT  
ICR - INSTRUMENT CHAMBER ROOM  
ICVS - INSTRUMENT CHAMBER VACUUM SUBSYSTEM  
ID - INNER DIAMETER, INTERFACE DEFINITION  
ID GAUGE - INSIDE DIAMETER GAUGE FOR ODGM  
IDD - INTERFACE DEFINITION DOCUMENT  
IE - INCLUDED ENERGY  
IP - INSTRUMENTATION PROCESSOR  
IRD - INTERFACE REQUIREMENTS DOCUMENT  
IRU - INERTIAL REFERENCE UNIT  
ISC - INNER SUPPORT CYLINDER  
ISU - INSTRUMENT SWITCHING UNIT  
ITCV - INTEGRATED TEST CONFIGURATION VETA-1

J

JSC - JOHNSON SPACE CENTER

NOAO - NATIONAL OPTICAL ASTRONOMY OBSERVATORY

NSLS - NATIONAL SYNCHROTRON LIGHT SOURCE

NSTS - NATIONAL SPACE TRANSPORTATION SYSTEM

NVR - NON-VOLATILE RESIDUE

O

OA - OPTICAL AXIS

OAS - OPTICAL ALIGNMENT SYSTEM

OB - OPTICAL BENCH

OBA - OPTICAL BENCH ASSEMBLY

OBC - ON-BOARD COMPUTER

OD - OUTER DIAMETER

ODBF - OUTSIDE DIAMETER BLOCKING FIXTURE

ODGM - OUTSIDE DIAMETER GRINDING AND POLISHING MACHINE

ODGM - OUTSIDE DIAMETER GRINDING AND POLISHING MACHINE CSCI (PC BASED)

ODGM-PROCESS - ODGM ANALYSIS SOFTWARE CSC (VAX BASED)

OGM - OBJECTIVE GRATING MECHANISM

OM - OPERATIONS MANAGER CSC (VAX BASED)

OMV - ORBITAL MANEUVERING VEHICLE

OPM - OPTICAL POSITION MONITOR

OPS - OPTICAL POINT SOURCE

ORI - OPERATING READINESS INSPECTION

ORU - ORBITAL REPLACEABLE UNIT

OSC - OUTER SHIPPING CONTAINER

OSC - OUTER SUPPORT CYLINDER

OSM - OPTICAL STRUCTURE AND MECHANISMS

OTG - OBJECTIVE TRANSMISSION GRATING

P

P - PARABOLOID

PAO - PRODUCT ASSURANCE ORGANIZATION

PAS - PROBLEM ASSESMENT SYSTEM

PCADS - POINTING CONTROL AND ASPECT DETERMINATION SUBSYSTEM

PCH - PROGRAM CRITICAL HARDWARE

PCS - PROPORTIONAL COUNTER SUBSYSTEM

PD - PRELIMINARY DRAFT

PDA - PRELIMINARY DESIGN AUDIT

PDR - PRELIMINARY DESIGN REVIEW

PFRS - POSITIVE FLUID RETENTION SYSTEM

PHA - POLISHING HISTORY ANALYSIS SOFTWARE CSCI (VAX BASED)

PID - PROPORTIONAL INTEGRAL DERIVATIVE

PMB - PERFORMANCE MEASUREMENT BASELINE

PMM - PRECISION METROLOGY MOUNT

PMMR - PROGRAM MANAGER'S MONTHLY REVIEW

PM&P - PARTS, MATERIALS, & PROCESSES

PMS - PERFORMANCE MEASUREMENT SYSTEM

PMS - PRECISION METROLOGY STATION

SI - SCIENCE INSTRUMENTS  
SIAH - SCIENCE INSTRUMENT ACCOMMODATION HARDWARE  
SIM - SCIENCE INSTRUMENT MODULE  
SMG - SURFACE MAP GENERATION SOFTWARE CSCI (VAX BASED)  
SMS - SURFACE MONITORING SYSTEM  
SO - SERVICING OPERATIONS  
SPIE - SOCIETY OF PHOTO-OPTICAL INSTRUMENTATION ENGINEERS  
SPL - SOUND PRESSURE LEVEL  
SQCD - SUBAPERTURE QUADRANT CENTROID DETECTOR  
SR - SCHEDULE REVIEW  
SRR - SYSTEM REQUIREMENTS REVIEW  
SS - SPACE STATION  
SSA - S-BAND SINGLE ACCESS  
SSA - STRUCTURE SUPPORT ASSEMBLY  
SSE - SPACE SUPPORT EQUIPMENT  
SSS - SHIPPING SUPPORT STRUCTURE  
SSTA - STAR SENSOR TELESCOPE ASSEMBLY  
STA - STATION: ARCHITECTURAL COORDINATE SYSTEM  
STACC - STANDARD TELEMETRY AND COMMAND COMPONENT  
STDN - SPACECRAFT TRACKING AND DATA NETWORK  
STE - SPECIAL TEST EQUIPMENT  
STS - SPACE TRANSPORTATION SYSTEM  
SUBANAL - SUB-APERTURE ANALYSIS SOFTWARE CSC (VAX BASED)  
SVS - SOURCE VACUUM SUBSYSTEM  
S/W - SOFTWARE

**T**

TBD - TO BE DETERMINED  
TBR - TO BE RESOLVED / REVISED  
TBS - TO BE SUPPLIED  
TC - THERMAL CONTROL  
TCS - THERMAL CONTROL SUBSYSTEM  
TDRSS - TRACKING AND DATA RELAY SATELLITE SYSTEM  
TFA - TRANSFER FIXTURE ASSEMBLY  
TIM - TECHNICAL INTERCHANGE MEETING  
TIRF - TOWER INITIALIZATION REFERENCE FIXTURE  
TMA - TECHNOLOGY MIRROR ASSEMBLY  
TPA - THERMAL PANEL ASSEMBLY  
TPVS - THERMAL PRECOLLIMATOR VIGNETTING STUDY  
TR - TRIP REPORT  
TRD - TECHNICAL REVIEW DOCUMENTATION  
TRI - TILT REFERENCE INTERFEROMETER  
TRW - TRW, INC.  
TS - TELESCOPE SYSTEM  
TST - TECHNICAL SUPPORT TEAM  
TTC - TELESCOPE THERMAL CONTROL

**U**